

# Honeywell

Genuine Honeywell enviraire

True HEPA filter No.

# Replacement True HEPA Filter

**24000**  
Replaces filter #28500

*1 True HEPA filter included*

The performance rating of your Honeywell air cleaner is based exclusively on use with genuine Honeywell replacement filters.



**AMERICAN LUNG ASSOCIATION**  
Partners in Air Quality Education

## Installation Instructions:

Refer to owner's manual for additional instructions and safety guidelines.

1. Turn the air cleaner OFF and unplug from the wall outlet.
2. To open, unscrew the locking mechanism (Fig.1), and separate the lid from the base (Fig.2).
3. Remove the filter assembly (pre-filter and HEPA filter) from the internal chamber.
4. Remove the pre-filter from the HEPA filter (Fig. 3). Discard the HEPA filter.
5. Remove the new HEPA filter from its package. Carefully wrap the pre-filter around the new HEPA filter, and attach using the fasteners provided.
6. Place the filter assembly into the internal chamber, replace the lid and base, and tighten the locking mechanism. Turn air cleaner to an operable position.
7. Using the convenient HEPA Filter Change Reminder labels provided, peel off the next year you need to replace the HEPA filter (which is to 1 to 3 years from this change, depending upon use) and place it onto your air cleaner.
8. Plug air cleaner into a power outlet and it is ready for operation.





Fig. 1



Fig. 2



Fig. 3

Honeywell makes no warranties of any kind for this product, including merchantability and fitness for a particular purpose. In no event shall Honeywell, its employees, agents or representatives be responsible for any direct or indirect damages, including consequential and incidental damages.