

Media Replacement Schedule - Bulldog BD2KLA

1. H2002-12 - Pleated Particulate Pre-filter
 - a. Use filter indicator light to determine needs
 - b. High Particulate- estimate 72 hours
 - c. Medium Particulate - 3 x/ month
 - d. Low particulate- 1 x/ month or when filter light goes on

2. VL2024 - (Optional Vapor Lock Carbon Filter)
 - a. Use filter indicator light to determine needs
 - b. High Particulate- estimate 72 hours
 - c. Medium Particulate - 3 x/ month
 - d. Low particulate- 1 x/ month or when filter light goes on

3. H242406-99 - HEPA Filter
 - a. Every 9,000 hours
 - b. 1 year and a half (even if 9,000 hours has not been reached)

4. H2010 - (Optional HEPA filter)
 - a. Every 9,000 hours
 - b. 1 year and a half (even if 9,000 hours has not been reached)

5. H2010M - (Optional HEPA filter)
 - a. Every 9,000 hours
 - b. 1 year and a half (even if 9,000 hours has not been reached)