

## Media Replacement Schedule - PAS600

1. F621 - Coarse Particulate Filter
  - a. High Particulate- every 8 hours
  - b. Medium Particulate- every 48 hours
  - c. Low particulate- every 72 hours or until filter light goes on
  
2. H502 - Pleated Particulate Pre-filter
  - a. Use filter indicator light to determine needs
  - b. High Particulate- estimate 72 hours
  - c. Medium Particulate- 3 x/ month
  - d. Low particulate- 1 x/ month or when filter light goes on
  
3. VL1002 - (Optional - Vapor Lock Carbon Filter)
  - a. The VL1002 replaces the H502 2<sup>nd</sup> stage pre-filter.
  - b. The method of determining when to replace the activated carbon filter is somewhat subjective. As the odor, vapor, and/or gas filtration capacity decreases, the user will begin to sense a slight odor or taste of the contaminant, indicating that the filter should be replaced.
  
4. H610C-99 - HEPA Filter
  - a. Every 9,000 hours
  - b. 1 year and a half (even if 9,000 hours has not been reached)